



Versatile Keratin Bond Connector

Lightweight Compact Tool for Precision Installation

Rapid Dual-Side Heating

Constant Temperature

Versatile Tip for a Wide Range of Invisible Bonds

Long Lasting Easy-Clean Teflon Plates

Flat Plates Perfect for Flat Keratin Bonds



READ ALL INSTRUCTIONS BEFORE USING AND SAVE THESE INSTRUCTIONS

SPECIFICATIONS

Rated voltage: 110V-240V 50/60HZ / US standard plug

Rated power: 25W

Temperature range: 80°-220°C (Celsius)

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

DANGER-To reduce the risk of electrocution:

- Always unplug this appliance immediately after using.
- Do not use while bathing.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.

WARNING! To reduce the risk of burns, electrocution, fire or injury to persons:

- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used near children or individuals with certain disabilities.
- Do not allow children to use this appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never place the appliance on a soft surface, such as a bed or couch.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- The appliance tip is hot when in use. Do not let eyes and bare skin touch heated surfaces.
- Do not place the appliance directly on any surface while it is hot or plugged in.
- Never use while sleeping.
- Always use a heat shield to protect the scalp.

GENERAL USE

1. Insert the power cord firmly into a suitable wall outlet.
2. Turn the ON/OFF switch to the ON position.
3. Adjust the temperature using the dial.
4. Wait 1 minute for plates to reach the desired temperature.
5. When done, turn the switch to OFF and unplug the iron. Wait for iron to cool fully before storing.

TEMPERATURE CONVERSION

The appliance displays temperature in °C (Celsius). This is not the same as °F (Fahrenheit). If the bond you are applying specifies a °F temperature, use the conversion chart below. Always use a heat shield to protect the scalp from burns.

180°C	=	356°F	Lowest temperature for F&T K-Tips (not recommended)
190°C	=	374°F	Medium temperature for F&T K-Tips
200°C	=	392°F	Highest temperature for F&T K-Tips

WARRANTY

LDM warrants to the original purchaser that the product is free from defects in materials and workmanship for a period of ninety (90) days from the date of purchase. LDM will, at its discretion, repair a defective product with new or refurbished parts, or replace the product with the same or equivalent product, during the warranty period. This warranty gives you specific legal rights; you may also have other rights which vary from State to State. This ninety (90) day limited warranty applies only to products that are free from damage caused by accident, abuse, misuse, mishandling, improper installation, operation outside of the permitted or intended uses.