

# F&T x V

Micro Strands by Frame & Thread x V-Light



## Micro Strands by Frame & Thread x V-Light Bonding Light

Lightweight Compact Mini Tool for Precision Mess-Free Bonds

Hand-Held

Fast Heat-Free LED Cold-Bonding

Rechargeable With 2-3 Hours of Continuous Use

10 Second Auto-Shutoff

Includes Quick-Connect Neck Strap and Protective Shield

**For Trained Professional Licensed Cosmetologist Use Only!**

Micro Strands by Frame & Thread x V-Light are NOT the same as standard V-Light bonds.  
These instructions ONLY apply to Micro Strands by Frame & Thread x V-Light.



## **READ ALL INSTRUCTIONS BEFORE USING AND SAVE THESE INSTRUCTIONS**

### **SPECIFICATIONS**

Charging voltage: 5V (provided by external USB brick (not included))

Charging current: 2A

Rated power: 15W

Useable charge time: >2 hours

Light range: 8-50mm

Effective curing distance: 5-10mm

Use temperature range: 5°–40°C (Celsius)

### **IMPORTANT SAFETY INSTRUCTIONS**

The light should not be used if the treated person has any of the following symptoms in the area of the head where the light from the system may shine: abrasions, keloid scars, unhealed scars, herpes, psoriasis, other infectious or inflammatory skin diseases, fungal infections, wounds, sunburn, neurodermatitis, or skin cancer. The light should not be used if the user or the person being treated has the following conditions: epilepsy, polymorphous light dermatosis, photosensitivity, or hemophilia. The light should not be used if the treated person is undergoing radiation or chemotherapy. The light should not be used if the user or treated person is taking photosensitizing medication such as neuroleptics, systemic dermatics, and antiepileptics. The treatment of pregnant or breastfeeding persons may only be carried out after prior consultation with a doctor. In case of doubt, treatment should be avoided. When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

#### **DANGER! To reduce the risk of electrocution or malfunction:**

- Always unplug this appliance immediately after using.
- Do not use while bathing.
- Do not place or store appliance where it or its power brick, can fall or be pulled into a tub or sink.
- Do not place in or drop into liquid. Do not use product or its power brick around or expose to any liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.

#### **WARNING! To reduce the risk of burns, eye injury, electrocution, fire, or other injury to persons:**

- Never look directly at the light. Never shine the light into any person's eyes. Never shine the light into any animal's eyes.
- Always use the correct voltage.
- The appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used near children or individuals with certain disabilities.
- Always lock this appliance up when not in use. Do not allow children to access, handle, or use this appliance.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- This appliance should never be hot to the touch. If it is hot, move it to a safe place outdoors away from flammable materials, people, and animals.
- Do not use an extension cord with this appliance.
- Always use the protective light shield.
- Do not use if auto-shutoff timer function is not working. Do not attempt to bypass the auto-shutoff timer.
- No user-serviceable parts inside. Never attempt to open or repair the V-Light.
- Contains Lithium batteries. Always store in a cool dry place, never in a hot environment or car.
- Do not attempt to charge if the V-Light, cord, or power brick are damaged in any way.
- Follow all laws regarding the safe disposal of V-Light when it is no longer usable.

### **GENERAL USE**

1. Follow all instructions in Frame & Thread's educational video series on Micro Strands by Frame & Thread x V-Light.
2. Insert the power cord firmly into the charging port on the V-Light and then into a suitable USB power brick.
3. While charging, the indicator light will be RED.
4. When done charging, the indicator will turn GREEN and V-Light should be unplugged.
5. Slide the ON/OFF switch to ON to set V-Light into standby mode.
6. Press the white, round power button to activate the V-Light.
7. Press the power button again to deactivate the light or wait 10 seconds for auto-shutoff.
8. May be used with power cord if you forget to charge. Use caution not to pull, bend, or put tension on the cable.
9. When done using, slide the ON/OFF switch to OFF.

### **WARRANTY**

V-Light warrants to the original purchaser that the product is free from defects in materials and workmanship for a period of one year from the date of purchase. V-Light will, at its discretion, repair a defective product with new or refurbished parts, or replace the product with the same or equivalent product, during the warranty period. This warranty gives you specific legal rights; you may also have other rights which vary from State to State. This one year limited warranty applies only to products that are free from damage caused by accident, abuse, misuse, mishandling, improper installation, operation outside of the permitted or intended uses.